

**HEAVY DUTY
BORED
LOCKSET**

IMPORTANT
FOLD HERE ON
HIGH EDGE OF
BEVELED DOOR

BORE $2\frac{1}{8}$ "
HOLE THRU
DOOR
FIRST

$2\frac{3}{8}$ " BACKSET

$2\frac{3}{4}$ " BACKSET

$1\frac{3}{4}$ " DOOR
 $1\frac{3}{8}$ " DOOR
Ø Ø

FOR $2\frac{3}{8}$ " BACKSET
MARK FOR $\frac{7}{8}$ " DIA.
HOLE AT CENTER
OF DOOR THICKNESS,
1" DIA. HOLE FOR
 $2\frac{3}{4}$ " BACKSET.
DRILL THRU INTO
CROSS BORE HOLE,
PARALLEL TO SIDES
OF DOOR.

DETERMINE CORRECT BACKSET
AND DOOR THICKNESS - THEN
PLACE TEMPLATE ON DOOR
AND MARK FOR HOLES.

B91/P91

