

**HEAVY DUTY  
BORED  
LOCKSET**

**IMPORTANT  
FOLD HERE ON  
HIGH EDGE OF  
BEVELED DOOR**

BORE  $2\frac{1}{8}$ "  
HOLE THRU  
DOOR  
FIRST

$2\frac{3}{8}$ " BACKSET

$2\frac{3}{4}$ " BACKSET

$1\frac{3}{4}$ " DOOR  
 $1\frac{3}{8}$ " DOOR  
Ø Ø

FOR  $2\frac{3}{8}$ " BACKSET  
MARK FOR  $\frac{7}{8}$ " DIA.  
HOLE AT CENTER  
OF DOOR THICKNESS,  
1" DIA. HOLE FOR  
 $2\frac{3}{4}$ " BACKSET.  
DRILL THRU INTO  
CROSS BORE HOLE,  
PARALLEL TO SIDES  
OF DOOR.

DETERMINE CORRECT BACKSET  
AND DOOR THICKNESS - THEN  
PLACE TEMPLATE ON DOOR  
AND MARK FOR HOLES.

B91/P91

